

Meridian IVR

Planning and Engineering Guide

Publication number: 555-9001-200
Product release: Meridian IVR 2.0/I
Document release: Standard 1.0
Date: February 1996

© 1996 Northern Telecom
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

Nortel, Meridian IVR, Meridian Mail, ACCESS, and Meridian 1 are trademarks of Northern Telecom. DEC and VT420 are trademarks of Digital Equipment Corporation. HP, LaserJet, and ThinkJet are trademarks of Hewlett-Packard Company. NCD is a trademark of Network Computing Devices Inc. UNIX is a registered trademark of AT&T. Voicetek and VTK are trademarks of Voicetek Corporation. Motif is a trademark of Open Software Foundation Inc. Touch tone is a trademark of Bell Canada.

Publication history

February 1996

This document is the first standard issue for Meridian IVR release 2.0/I.

Contents

About this guide	xi
Who should use this guide	.xi
How to use this guide	.xi
Related documentation	xii
IVR 2.0/I documentation	.xiii
Third party documentation	.xiii
Conventions used in this guide	.xiv

Chapter 1: Understanding Meridian IVR	1-1
Meridian IVR specifications	1-1
Hardware and software	1-1
System administration	1-1
Platform and release dependencies	1-1
Supported Meridian IVR software	1-2
About Meridian ACCESS	1-3
Preconfiguration requirements	1-3
Meridian Mail	1-3
Private branch exchange	1-4
Meridian IVR hardware platform	1-5

Chapter 2: What you need to know	2-1
System performance	2-1
Factors affecting system performance	2-1
Host access	2-1
ACCESS link capacity	2-1
Application digit density	2-2
Fax conversion processes	2-2
Number of voice prompts played	2-2
The Meridian Mail system	2-2

Chapter 3: Recommended sizing procedures	3-1
Meridian IVR software	3-1
Base software packages	3-1
Host communication software	3-1
5250 host connectivity	3-3
Other host connectivity	3-3
Meridian IVR Fax Response software	3-3
SQL database support	3-4
Traffic principles	3-4
Terminology	3-4
Meridian IVR traffic model	3-5
Fax response traffic model	3-6
Storage calculations	3-10
Types of channels	3-10
Estimating the number of channels	3-11
Ongoing channel sizing	3-16
Control of maximum number of channels	3-17
Deciding between dedicated and shared channels	3-17
Sharing channels among IVR applications	3-18
Outcalling applications	3-18
Determining hours of storage	3-18
Ongoing disk management	3-20
Performance tips	3-21
Determining the correct number of ACCESS links	3-21
Database servers and host sessions	3-22
Memory and CPU requirements	3-23
Memory sizing	3-24
The point system	3-24
CPU sizing	3-28
Disk sizing	3-30

Chapter 4: Configuring your Meridian IVR system	4-1
Base system software configuration	4-1
Modifying the UNIX system configuration	4-1
Physical I/O port configuration	4-2
Interrupt requests and system I/O map	4-5
Meridian IVR and MMail configuration	4-7
Voice and telephony resources configuration	4-9
The channel allocation table	4-9
The voice services directory number table	4-9

Outcalling channels	4-9
Meridian IVR resources configuration	4-10
Channel configuration on Meridian IVR	4-10
Mixed mode	4-10
Disk usage	4-10
Disk partitioning	4-10
Prime hard disk drive	4-11
Second hard disk	4-11
How Meridian IVR is configured	4-12

Chapter 5: Planning applications **5-1**

Types of applications	5-1
Incoming call (inbound) applications	5-2
Outgoing call (outbound) applications	5-2
Administrative applications	5-2
Concepts and planning	5-3
Private branch exchange	5-3
Meridian Mail	5-4
General procedure for planning an application	5-6
More on preconfiguration requirements	5-7
Storage (disk space)	5-7
Voice channels	5-8
Application planning	5-10
Before you start	5-10
Determine your needs	5-10
Draw a flowchart	5-11

Appendix A: Sample configurations **A-1**

Shared IVR channel configuration (single application)	A-1
Shared IVR channel configuration (multiple applications)	A-4
Dedicated IVR channel configuration	A-8
Hybrid Meridian IVR channel configuration	A-11
Shared configuration: voice channels exceed logical channels	A-13
Configuration notes for Meridian Mail Release 9 systems	A-16
Single port type	A-17
Mixed port types	A-18
Meridian IVR configuration notes	A-20
General information	A-20
Configuring an isolated test environment	A-22
Interaction with Customer Controlled Routing	A-23

Appendix B: Equipment ordering information	B-1
Appendix C: System capacity limits	C-1
Appendix D: Optional software packages	D-1
Appendix E: Valid Meridian IVR upgrades and expansions	E-1
Appendix F: Relational database software	F-1
Appendix G: Erlang tables	G-1
Appendix H: Power consumption	H-1
Glossary	Glossary-1

List of figures

Figure 4-1	Configuring the AP with MMail (Pre MM10)	4-8
Figure 5-1	Meridian IVR-based application overview	5-3
Figure 5-2	Sample application flowchart	5-11
Figure A-1	Single application, shared model configuration: Meridian Mail/Meridian IVR	A-3
Figure A-2	Single application, shared model configuration: Meridian 1/SL-1 ACD	A-3
Figure A-3	Multiple applications shared model configuration: Meridian Mail/Meridian IVR	A-5
Figure A-4	Multiple applications shared model configuration: Meridian 1/SL-1 ACD	A-6
Figure A-5	Sample application selector program for Meridian IVR	A-7
Figure A-6	Dedicated model configuration: Meridian Mail/Meridian IVR	A-11
Figure A-7	Hybrid model configuration: Meridian Mail/Meridian IVR	A-12
Figure A-8	Dedicated model configuration: Meridian 1/SL-1 ACD	A-13
Figure A-9	8 Dedicated Voice Mail and 12 Shared	

	Channels	A-15
Figure A-10	Configuring 20 Meridian Mail agents with 12 Meridian IVR logical channels.....	A-16
Figure A-2	Altserver motherboard slots	H-3

List of tables

Table 1-1	Compatibility with Meridian Mail.....	1-2
Table 2-1	Digit Density rate	2-2
Table 3-1	Example table for GOS P.05.....	3-13
Table 3-2	IVR_Fax_1 holding time values	3-14
Table 3-3	IVR_Fax_2 holding time values	3-14
Table 3-4	IVR_Fax_3 holding time values	3-15
Table 3-5	Example table for GOS P.05 and P.02	3-15
Table 3-6	Port addition increment for Fax and IVR	3-16
Table 3-7	ACCESS link capacity limits.....	3-21
Table 3-8	Scenario table for Memory and CPU requirements	3-23
Table 3-9	List of Meridian IVR Processes	3-25
Table 3-10	CPU point requirements	3-28
Table 4-1	Device name and legends.....	4-2
Table 4-2	Interrupt/Memory address and I/O port address list	4-6
Table 4-3	Prime disk partitioning configuration	4-11
Table 5-1	Determining channel capacity Meridian IVR	5-9
Table A-1	Mixed port configuration, all channels in service...	A-18
Table A-2	Mixed port configuration, basic ports out of service	A-19
Table B-1	Detailed Hardware component Description and List.....	B-1
Table C-1	ACCESS Link.....	C-1
Table C-2	Capacity limits	C-2
Table D-1	Meridian IVR Optional Software Packages	D-1
Table E-1	Valid/invalid system upgrades.....	E-1
Table E-1	Valid/invalid system expansions	E-1
Table F-1	RDBMS interface modules.....	F-1
Table G-1	Grade of service and traffic formula	G-1
Table G-2	Erlang-C traffic capacity (ccs) at P.05 for ACD (8 meg card option)	G-2
Table G-3	Erlang-C traffic capacity (ccs) at P.05 for ACD	G-2
Table G-4	Erlang-C traffic capacity (ccs) at P.05 for UCD/MSM	G-4

Table G-5	Erlang-B Traffic capacity (CCS) at P.02 (DMS-10 MLHG)	G-5
Table G-6	Fax GOS for P.05 Erlang-C	G-6
Table G-7	Fax GOS for P.02 Erlang-B.....	G-7
Table H-1	Power consumption calculation for MIVR 2.0/I	H-1